TRAID & TELEHEALTH VOLUME, HOME & OTHER BUTTONS

Support for users accessing an iPad for telehealth visits



Justice Center for the Protection of People with Special Needs

TYPES OF iPADS



BUTTONS

VOLUME BUTTONS

Use to adjust the volume when listening to music, watching videos, or playing games

TOP BUTTON

Press to wake your device or put it to sleep. Press and hold the top button to turn your device off or on

HOME BUTTON



If your device has a home button, it will be located on the front screen. It can unlock the iPad or take you to the Home screen

BATTERY & WIFI INFORMATION

BATTERY & WIFI LOCATION

Located at the top of the screen



WIFI STRENGTH

The more bars the stronger the signal



BATTERY LIFE

The fuller the battery icon or the higher the number, the longer the battery should last





Justice Center for the Protection of People with Special Needs

CHARGING AN iPAD BATTERY

Check the border of the iPad to locate the port. Plug the iPad's charger into the port and to its included adapter. Then plug the adapter into a wall outlet.

When an iPad is charging a lightning bolt will appear in the battery icon. If the volume is turned on, then there will be a small chime when you plug in the charger.



HAVE QUESTIONS ABOUT YOUR IPAD?

Reach out to your local TRAID Center with questions about telehealth at:

1-800-624-4143



SCAN CODE FOR VIDEO TUTORIALS

The Justice Center has compiled a series of helpful video tutorials to better assist you with using an iPad for telehealth videos. Scan the QR code at the left to access the playlist.